



Enduro FIT App Phone Settings - Android

Here are the essential Android phone settings that are required after installing the Enduro FIT app from Google Play. Once modified you should not need to check or change the settings unless you install a new app version. This assumes you accept all the permission and setting requests after opening the app for the first time after installation.

- 1) When Enduro FIT is running, it needs permission to access the phone's GPS location data. This setting will ensure your ride tracking is accurate and recorded throughout your ride, including when the screen is off.
 - a) Go to Settings > Apps > Enduro FIT > Permissions > Location
 - b) Make sure Location Permission is set to 'Allow all the time'
 - c) Ensure Precise Location is on
- 2) When Enduro FIT is running and connected to a Bluetooth Heart Rate Sensor, it needs permission to access the heart rate data from this nearby device. This setting will ensure your horse's heart rate is recorded throughout your ride, including when the screen is off.
 - a) Go to Settings > Apps > Enduro FIT > Permissions > Nearby Devices
 - b) Make sure Nearby devices permission is set to 'Allow'

Note, for items 1 and 2 ensure Enduro FIT permissions are not automatically modified by the phone if the app is not used for a period of time.

- a) Go to Settings > Apps > Enduro FIT
- b) Ensure 'Remove permissions if app is unused' is off

Enduro FIT App Troubleshooting guide - Android

- 1) Ensure your phone's power saving mode is off when using the Enduro FIT app.
 - a) Go to Settings > Battery
 - b) Make sure Power Saving is off
- 2) Ensure Location is on to allow for Enduro FIT app GPS Ride Tracking.
 - a) Go to Settings > Location
 - b) Make sure Location is on.
- 3) Bluetooth is required to connect the Enduro Equine HRM to the Enduro FIT app.
 - a) Go to Settings > Connections
 - b) Make sure Bluetooth is on
- 4) Once Bluetooth is on, only Pair the HR sensor using the Enduro FIT app (HR sensor screen). DO NOT pair the HR sensor using the Phone's Bluetooth settings screen.
- 5) Turn off battery usage optimisation for the Enduro FIT app.
 - a) Go to Settings > Apps > Enduro FIT > Battery
 - b) Set to Unrestricted (if option is available)
- 6) Turn off battery usage optimisation for the Enduro FIT app.
 - a) Go to Settings > Battery > More Settings > Optimise battery use > Enduro FIT
 - b) Make sure this is set to 'Don't Optimise' (if option is available)
- 7) Allow Enduro FIT to operate in the background, including when the screen is off.
 - a) Go to Settings > Apps > Enduro FIT > Battery
 - b) Make sure 'Allow background activity' is on (if option is available).