



Enduro FIT App Phone Settings - iPhone

Here are the essential iPhone settings that are required after installing the Enduro FIT app from the App Store. Once modified you should not need to check or change the setting unless you install a new app version. This assumes you accept all the permission and setting requests after opening the app for the first time after installation.

- 1) When Enduro FIT is running, it needs permission to access the phone's GPS location data. These settings will ensure your ride tracking is accurate and recorded throughout your ride, including when the screen is off.
 - a) Go to Settings > Enduro FIT > Location
 - b) Make sure ALLOW LOCATION ACCESS is set to 'Always'
 - c) Ensure Precise Location is on

Enduro FIT App Phone Troubleshooting Guide - iPhone

- 1) Ensure your phone's low power mode is off when using the Enduro FIT app.
 - a) Go to Settings > Battery
 - b) Make sure Low Power Mode is off
- 2) Ensure Location Services are on to allow for Enduro FIT app GPS Ride Tracking.
 - a) Go to Settings > Privacy & Security > Location Services
 - b) Make sure Location Services is on.
- 3) Bluetooth connectivity is required to connect the Enduro Equine HRM to the Enduro FIT app. The Enduro FIT app must also have Bluetooth access permission.
 - a) Go to Settings > Bluetooth
 - b) Make sure Bluetooth is on
 - c) Go to Settings > Enduro FIT
 - d) Allow Enduro FIT to Access Bluetooth
- 4) Once Bluetooth is on, only Pair the HR sensor using the Enduro FIT app (HR sensor screen). DO NOT pair the HR sensor using the Phone's Bluetooth settings screen.
- 5) Mobile Data must be on to allow the Enduro FIT app to sync ride data with the Enduro Equine secure Cloud database . Mobile data is also required for live ride tracking. The Enduro FIT app must also have Mobile Data access permission.
 - a) Go to Settings > Mobile Data
 - b) Make sure Mobile Data is on
 - c) Go to Settings > Enduro FIT
 - d) Allow Enduro FIT to Access Mobile Data
- 6) Enduro FIT uses the phone's motion sensors for improving ride tracking and for analysing the horse's gait and schooling.
 - a) Go to Settings > Enduro FIT
 - b) Allow Enduro FIT to Access Motion & Fitness